

Adapter INSTRUCTIONS for aftermarket Ruger 10/22 Magazines

1. Choose the correct adapter for your magazine. Put at least one round in your magazine and look how the back of the rimmed cartridge lines up with the centerline of the magazine. It will be either **CENTERED** (Shooters Ridge, Butler Creek), or **OFF-CENTER** to the left (RamLine, Eagle).

2. Hold the loader in your left hand, and press the adapter lock with your thumb. With your right hand, hook the Mag Adapter into the top of the Lightnin' Grip Loader and swing the bottom into the slot. Take your thumb off of the lock button. It should pop out to the locked position when the adapter is in fully seated.

3. Insert your magazine into the adapter until the small magazine pin hooks under the latch.

Lightnin' Grip Loader INSTRUCTIONS

1. Slide open the Bullet Reservoir Cover and drop in up to fifty (50) 22LR cartridges.

2. Close cover. Gently shake the Cliploader, keeping it level and the reservoir cover on top.

3. Raise the reservoir end to slide the cartridges in to the Loading Channel.

4. Repeat #2 and #3 until the Loading Channel fills sufficiently.

5. Raise the reservoir end and smoothly squeeze the trigger to load a round into the magazine. The trigger needs to return to the nearly out position to seat the round and stage another bullet for loading. It is usually a good idea to count the bullets going in to know when to stop. It is possible to force in an extra round.

NOTE: Quickly snapping the trigger in can cause the bullets to bounce in some magazines and "hook" the rims in the wrong direction making them hard to get out. Sometimes a hard rap on the bottom of the magazine with your palm or on a book will bounce the bullets to unhook them.

TIPS:

- Bullets are not feeding-----
Some 22LR cartridges are real sticky with wax lube. After filling the reservoir, give them a shot of Remington (Rem Oil) Teflon Spray Lube. Only a small amount is needed. Caution! The unit is molded from Lexan, and some lubes will attack it.
- Not all magazines fit the same; you may need to apply a little seating pressure against the magazine as you are loading it. As pictured.
- Periodically take a look at our website for updated tips

P/N LGL22

