

TROUBLESHOOTING-----Bullets stop feeding into magazine.

We've recently heard of a couple loaders that stopped working. In the "heat of battle" at the range the shooter has the tendency to quickly slam the magazine into the Cliploader. Quick is ok. Hammering the magazine to the stop inside the loader isn't. This is kicking up a burr inside the loader that stops the shells from going into the magazine.

If this happens, you can scrape the burr with a knife to remove it. Nothing should stick up above the surface where the cartridges slide except the ball.

Note: Never adjust the plug holding the ball and spring. This should always stay bottomed out to provide the correct ball action.



Damage from
the magazine
being jammed
into the loader